



U.S. Department of Energy
Office of Civilian Radioactive Waste Management



Newer Alloy 22 Data and Their Relevance to High-Temperature Localized Corrosion

Presented to:

Nuclear Waste Technical Review Board

Workshop on Localized Corrosion of Alloy 22 in Yucca Mountain Environments

Presented by:

Raul B. Rebak

Senior Scientist, Lawrence Livermore National Laboratory

25-26 September 2006

Las Vegas, NV

Data Generators - LLNL

- **Gregory E. Gdowski**
- **Susan A. Carroll**
- **Tiangan Lian**
- **Suvasis Dixit**
- **Sean J. Felker**
- **Joel R. Hayes**
- **Sarah K. Roberts**
- **Philip D. Hailey**
- **Kirk J. Staggs**
- **Christine A. Orme**



Outline

- **Introduction**
- **Environment (Felker Report)**
 - **What type of Na and K solutions are possible at high temperature?**
- **Autoclave Tests (Dixit Report)**
 - **General and crevice corrosion susceptibility**
- **Anodic Polarization at High Temperature**
 - **What nitrate over chloride ratio is necessary to inhibit crevice corrosion?**
- **Conclusions**



Introduction

- **N06022 is susceptible to crevice corrosion in chloride-containing aqueous solutions**
- **Susceptibility is influenced by chloride concentration, temperature, electrochemical potential and nitrate concentration**
- **Nitrate inhibits crevice corrosion initiation and propagation**
- **A minimum ratio of $[\text{NO}_3]/[\text{Cl}]$ may be needed for localized corrosion inhibition**
- **At $T < 120^\circ\text{C}$, this ratio may vary between $\frac{1}{2}$ to 2, depending on other experimental variables**




Environments Based on K and Na Salts (Felker Report)



Brine Compositions at High Temperature

Source: UCRL-TR-218195



Notes on Environments for K and Na Brines

- Using Na and K salts, it is not possible to make chloride-rich brines that would have boiling temperatures higher than 120°C
- All Na and K based brines with boiling temperatures higher than 120°C will have $[\text{NO}_3]/[\text{Cl}]$ ratios higher than 5
- Crevice corrosion was not observed in Alloy 22 using short-term tests at $[\text{NO}_3]/[\text{Cl}]$ ratios higher than 2
 - Except for the closed autoclave tests, which were performed at $[\text{NO}_3]/[\text{Cl}]$ ratios lower than those for stable solutions



Autoclave Experiments (Dixit Report)



Why the Autoclave Experiments?

- The latest autoclave experiments were designed as a follow-on of previous tests to determine the general corrosion rate of Alloy 22 at temperatures higher than 150°C
- Creviced specimens were included in the autoclaves to test the hypothesis that a $[\text{NO}_3]/[\text{Cl}]$ ratio higher than 0.5 would not initiate crevice corrosion in Alloy 22
- The autoclave experiments were not designed to mimic the high nitrate brines expected for the in-drift environment



Autoclave Experiments

Details in the Dixit Report (UCRL-TR-217393)

- Alloy 22 specimens, all non-welded polycrystalline material
- Three types of specimens
 - Pucks (5/8" diameter 3 mm thick discs – ASTM G 61)
 - ◆ Non-creviced for surface analysis
 - 50 μm thick foils
 - ◆ Non-creviced for corrosion rate by weight loss
 - 50 μm thick foils
 - ◆ Creviced for crevice corrosion initiation studies
 - ◆ Crevice former = alumina 12-tooth washer. No PTFE tape




Autoclave Experiments

- Autoclaves purged with nitrogen before heaters turned on
- Autoclave 1
 - 160°C
 - 2.5 *m* NaCl + 3.4 *m* NaNO₃ + 15.1 *m* KNO₃, [NO₃]/[Cl] = 7.4
 - Crevice corrosion initiation was not anticipated, but occurred
- Autoclave 2
 - 220°C
 - 2.5 *m* NaCl + 3.4 *m* NaNO₃ + 15.1 *m* KNO₃, [NO₃]/[Cl] = 7.4
 - Crevice corrosion initiation was not anticipated, but occurred
- Autoclave 3
 - 220°C
 - 6.4 *m* NaCl + 3.2 *m* KNO₃, [NO₃]/[Cl] = 0.5
 - Crevice corrosion initiation may be expected, and occurred



Brine Compositions at High Temperature



Autoclave Experiments

- **Specimens tested in the vapor and liquid regions in each autoclave**
- **Total of 30 specimens per autoclave**
 - **Pucks = 8 (4 in the vapor and 4 in liquid)**
 - **Weight-loss Foils = 12 (6 in vapor and 6 in liquid)**
 - **Creviced Foils = 10 (4 in vapor and 6 in liquid)**
- **Total testing time was 267 days (9 months)**
 - **Tests started 9-13 September 2004**
 - **Autoclave heaters turned off 22 June 2005**



Three Type of Results from Autoclave Tests

- **Crevice corrosion initiation susceptibility**
- **Surface deposits and corrosion products composition information**
- **Corrosion rate by weight loss**



Crevice Corrosion (CC) Results from Autoclave Experiments

- The creviced specimens showed deposits from dissolved crevice formers
- Specimens exposed to all the tested conditions had crevice corrosion both in the vapor and liquid phases
 - Autoclave 1 (160°C), $[\text{NO}_3]/[\text{Cl}] = 7.4$
 - Autoclave 2 (220°C), $[\text{NO}_3]/[\text{Cl}] = 7.4$
 - ◆ At 220°C, less attack in the liquid than in the vapor
 - ◆ There was less attack at 220°C than at 160°C (same electrolyte)
 - Autoclave 3 (220°C), $[\text{NO}_3]/[\text{Cl}] = 0.5$
 - ◆ Similar amount of crevice corrosion for Autoclave 2 and 3 (same temperature, different electrolyte)




Crevice Specimens - Autoclave 1

$[\text{NO}_3]/[\text{Cl}] = 7.4$
 160°C

Vapor

Liquid



Liquid
C105

X4000 Mag.



Crevice Specimens - Autoclave 2



Vapor ←

$[\text{NO}_3]/[\text{Cl}] = 7.4$
220°C



Liquid →




Crevice Specimens - Autoclave 3



$[\text{NO}_3]/[\text{Cl}] = 0.5$
220°C

Vapor

Liquid



Deposits

Liquid
C107

X80 Mag.



Auger and XPS Surface Analysis Results from Autoclave Experiments

- **Strong signals for O, C, Al and Si (Auger)**
 - Al and Si are foreign elements
- **Metals from the solution such as Na, K and in lower levels Ca and Mg also detected (Auger)**
- **Profiles show thinner surface oxides in the vapor (15 nm) than in the liquid (30 to 500 nm) (Auger)**
- **AC 1 samples have the thinnest oxides (Auger)**
- **Ni, Cr, Fe and W were detected on the surface as oxides or hydroxides (XPS)**



Corrosion Rate Results from Autoclave Experiments

- All the weight-loss foils in the three autoclaves showed mass gain even after up to 30 acid cleaning steps
- Weight difference between before-and-after tests was small (10 to 70 μg) (equivalent to -10 nm/year)
- Little or no general corrosion after 9 months at 160°C and 220°C
- Corrosion potential (E_{corr}) was not measured
 - E_{corr} was probably not in the transpassive region since little corrosion was observed



Notes From Autoclave Tests Results

- All the creviced specimens in the three autoclaves showed crevice corrosion initiation
- Tests were conducted in environments that are physically impossible in the repository
- Unanticipated crevice corrosion results from AC 1 and AC2 where $[\text{NO}_3]/[\text{Cl}] = 7.4$
- Short-term, fully immersed, cyclic potentiodynamic polarization would have predicted that at $[\text{NO}_3]/[\text{Cl}] = 7.4$ crevice corrosion would not have occurred up to $\sim 120^\circ\text{C}$
- To reach a stable solution at 160°C in a repository-type environment the ratio of $[\text{NO}_3]/[\text{Cl}]$ has to be near 100



Why Did Crevice Corrosion Occur in the Autoclave Tests?

- **There are several possible explanations**
 - **Chemical modification in the electrolyte or in the passive film due to the crevice former dissolution**
 - **At the temperature the tests were performed a higher absolute amount of nitrate may be needed to provide inhibition**
 - ◆ **The ratio to provide inhibition may be temperature dependent**
- **There may still be a need to investigate, under physically attainable natural conditions, the effect of time on crevice corrosion initiation and propagation (stifling) for $[\text{NO}_3]/[\text{Cl}]$ higher than 1 in dust-like environments (Na and K brines)**



Repassivation Potential Tests in K and Na Based Brines Short-Term Testing



NaCl + KCl + NaNO₃ + KNO₃ Brines

- Binary, ternary and quaternary salt mixtures 110°C to 150°C
- Solutions included
 - From pure Cl (8 *m*) to pure NO₃ (42 *m*)
 - Mixtures Cl and NO₃ at [NO₃]/[Cl] from 0.005 to 100
 - More than 30 solution compositions tested
 - ◆ Some pHs adjusted with HCl
- Short-term electrochemical tests
 - Cyclic potentiodynamic polarization (ASTM G 61)
 - Tsujikawa-Hisamatsu Electrochemical (THE)
 - Constant potential tests



Cyclic Polarization: Na and K Brines at 110°C


[NO₃]/[Cl] = 0



[NO₃]/[Cl] = 0.1




[NO₃]/[Cl] = 0.2



Increase in [NO₃]/[Cl] ratio resulted in shrinking of the hysteresis loop and drove the crevice corrosion attack deeper under the crevice former


[NO₃]/[Cl] = 0.3







[NO₃]/[Cl] = 0.5



[NO₃]/[Cl] = 1



High Nitrate Na and K Brines, 125°C to 150°C




No Localized Corrosion in Any High NO₃ Brine




Repassivation Potential, Na and K Brines, 110°C


No Crevice Corrosion



Crevice Corrosion Type I



Repassivation Potential, Ca and Na + K Brines, 125°C




- **Localized corrosion occurred only at [NO3]/[Cl] ratio of 0.5 (pitting corrosion) and at ratio of 1 (CC-II)**
- **For all other ratios higher than 1, no localized corrosion**
 - Type I crevice corrosion is shiny and of crystallographic appearance
 - Type II crevice corrosion is dull and happens at high anodic potentials (~>300 mV)



Repassivation Potential, Na + K Brines 140°C and 150°C

No Crevice Corrosion



- 140°C

- 3 m KCl + 38 m KNO₃ + 38 m NaNO₃
- 1 m KCl + 36 m KNO₃ + 36 m NaNO₃

- 150°C

- 1.5 m KCl + 1.5 m NaCl + 50 m KNO₃ + 50 m NaNO₃
- 0.5 m KCl + 0.5 m NaCl + 50 m KNO₃ + 50 m NaNO₃

- No localized corrosion in any of the tested conditions



Conclusions for Localized Corrosion Tests in Na and K Brines

- **Repassivation potential results shown were determined in fully immersed specimens in the bulk electrolyte**
- **Forced corrosion using a potentiostat (unlimited cathodic reaction)**
- **At atmospheric pressure, crevice corrosion was not observed for $[\text{NO}_3]/[\text{Cl}]$ ratios higher than 1**
- **Most detrimental range of temperature for Alloy 22 regarding localized corrosion would be below 120°C where lower $[\text{NO}_3]/[\text{Cl}]$ ratios could be naturally reached**



Final Remarks

- **Inhibiting effect of NO₃ is active at high temperatures**
- **Results shown are for fully immersed specimens in the electrolyte**
 - The amount of brine on the container will be small
- **Crevice corrosion is inhibited at [NO₃]/[Cl] ratios in the order of 0.5 to 2 and higher**
- **Dust deliquescence brines will be highly concentrated (or the activity of water in the brine will be low)**
 - The amount of metal that such brine can dissolve is minimal
- **Current results continue to support the localized corrosion model for degradation of the waste package**



Acknowledgments

- **This work was performed under the auspices of the U. S. Department of Energy by the University of California Lawrence Livermore National Laboratory under contract N° W-7405-Eng-48. This work is supported by the Yucca Mountain Project, which is part of the Office of Civilian Radioactive Waste Management OCRWM-DOE**
- **DISCLAIMER: This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.**




Backup Slides





Alloy 22 Specimens Used Prism Creviced Assembly (PCA)

WELDED PCA SPECIMEN



**GTAW
Seam**



**Hole for
Crevice Formers**



**Two Crevice Formers
With 12 Teeth Each
ASTM G 48**




Alloy 22 Specimens Used




MCA or Lollipop Specimens



Corrosion Test Specimens Prepared from Plates



Explanation of Parameters



- E20 and E200 are parameters for breakdown potential
- ER10, ER1 and ERCO are forms of repassivation potential
- For Alloy 22, E_{crit} is taken as a Rep. Pot., usually ERCO
- E_{corr} is the steady-state corrosion potential in naturally aerated brines
- If $E_{corr} \geq E_{crit}$, crevice corrosion is possible

